





EARTH POINTS

Connector No	Title	Location
C360	Airbag ECU earth eyelet	Below heater assembly
C362*	ABS return pump earth eyelet	Front RH side of engine compartment (common earth stud with C434)
C434*	ABS modulator earth eyelet	Front RH side of engine compartment (common earth stud with C362)
C556	LH reverse/tail lamp earth eyelet	Bottom rear corner of load space (common earth stud with C557)
C557	LH rear fog guard lamp earth eyelet	Bottom rear corner of load space (common earth stud with C556)



EARTH HEADERS

Connector No	Title	
C017	Earth header	Front LH side of engine compartment
C018	Earth header	Right front side of engine bulkhead
C550	Earth header	Below centre console
C551	Earth header	Bottom rear corner of load space
C553	Earth header	Front LH side of engine compartment

